
11383

MAZDA 3 5-DOOR

4/22/2011 INCLUDING SPEED 3 5-DOOR

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 2,000 LBS. TRAILER WEIGHT & 200 LBS. TONGUE WEIGHT.

DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.



HITCH WEIGHT: 29 LBS.
INSTALL TIME: 20 MINUTES
INSTALL NOTES:

- NO DRILLING REQUIRED

- FISHWIRE HARDWARE

TOOLS REQUIRED TORQUE WRENCH RATCHET EXTENSION 11/16" SOCKET 10mm SOCKET

DESIGNED FOR USE WITH BALLMOUNT #55001 / 45501

INSTALLATION STEPS

1. Fishwire CM-SP2 spacers and 7/16-14 carriage bolts through the access hole and out the holes in the bottom of the frame rails as shown. (See Fishwire Technique.)

FASCIA

- 2. Remove existing bolts securing the fascia tabs to the fascia brackets. Bolts will be reinstalled in step (5).
- 3. Pull down on fascia and slide hitch between the fascia tabs and the fascia brackets.
- 4. Align 7/16-14 carriage bolts fishwired in step (1) with holes in hitch and secure with 7/16" flange nuts.
- 5. Reinstall bolts removed in step (2).
- 6. Torque all 7/16" hardware to 50 ft-lbs

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Curt Manufacturing Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Curt Manufacturing Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Curt Manufacturing Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.