

## **INSTALLATION STEPS**

1) Enlarge holes in frame rails as shown.

2) Insert handle nut into hole as shown. Bending is required, handle end will stick out of existing frame rail hole.

3) Fishwire spacer through existing frame rail hole as shown.

4) Raise hitch into position and align holes.

5) Secure hitch to frame with remaining hardware.

## 6) Torque all 7/16" hardware to 70 lb-ft. and all 1/2" hardware to 110 lb-ft. **PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.**

Curt Manufacturing Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Curt Manufacturing Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Curt Manufacturing Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.