



Window Fur Channel Kits

INSTRUCTIONS

Getting Ready for Installation of Fur Strips and Channels

1. Remove old fur strips, cut old staples and then start by twisting up end of fur and cutting off. Remove the flexible channels above the door glass and channels around rear quarter glass. after removal clean out slot with mineral spirits and a small wire brush if necessary. If the original fur is no longer present look for remains of old staples or staple holes for more accurate location of fur strips.

Installation of Fur Strips (3/8" Flat Dusters)

1. On the interior and exterior side of the front doors note the fur strip has a straight end and a curved end, the straight end will be up by Division Bar (See **C** in Diagram Below). Use the original staple holes to help you locate correct positioning of fur strips.
2. On the interior body and exterior garnish moulding of the rear quarter align the fur to the body shape (See **D** in Diagram Below). Use the original staple holes to help you locate correct positioning of fur strips.
3. Hold fur and drill a 5/64" (.078") hole at one end, and progress towards the other end. Space holes about 6" apart. Using screws supplied in kit to attach fur strip.

CAUTION: Do not start at each end and work toward center. Drill each hole one at a time and install screw. This insures more accurate alignment.

4. Twist heads of screws with screwdriver to sink it into fur pile. The head of the screw should draw into the pile enough so it becomes invisible.

Installation of Division Bar (Non-Flexible U-Channel)

1. The complete vent window assembly must be removed from the door. This is also a good time to replace the vent window seal, Our part # 565A.
2. Drill out four rivets holding original fur channel. This will let the top part of the assembly to come apart. Install the new Division Bar, using hardware included in screw kit.

Installation of Flexible U-Channel

1. Before you start to install flexible channel make sure the stainless beads will slide back and forth this will allow the channel to bend without kinking. You can make small templates of the rounded corners of the glass out of piece of thin plywood of similar thickness.
2. On the front doors slide the channel into window opening. Now start in the corner by division bar, slide flexible channel in drill through channel and into door frame install screw, this will help hold it. Brush adhesive in the Body Channel and sides of Flexible Channel. Side the channel up into the back corner (use template if you made them).
3. On the rear doors slide the Flexible channel in the glass opening. Make sure the channel is positioned correctly, see Diagram below for example. Do the same process as the doors to attach to body. For positive mounting, use small screws in corners will help see diagram below.

Kit Includes:

- A. 2 - 32" Division Bar Channels
- B. 2 - 3/8"x20" Front Fur Strips
- C. 2 - 48" Flexible Channel
- D. 2 - 3/8"x26-1/2" Front Fur Strips
- E. 2 - 80-1/2" Flexible Channel
- 1 - Screw Kit

