

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX KIT: 19420**

2006-05 Dodge Dakota 3.7L, 4.7L
All Models, Dual Exhaust



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the old exhaust system from the vehicle. Use WD-40, or a similar lubricant, to aid in removing the rod hangers from the rubber isolators.
2. Install DynoMax front intermediate pipe **55255**. Insert the rod hanger into the rubber isolator coming off the RH frame. Finger tighten the front 2½" clamp.
3. Install DynoMax Super Turbo muffler **17758** at a 45° angle with the top of the muffler tilted toward the drive shaft. The top outlet connection is for the LH tail pipe, with the bottom connection for the RH tail pipe. Finger tighten the 2½" clamp on the connection to 55255.
4. Install RH tail pipe **47788** to the bottom outlet connection of the muffler. Install clamp-on rod hanger **36314** to the rubber isolator at the rear of the tail pipe. Finger tighten this clamp and the 2½" clamp that connects to muffler 17758.
5. Install outlet extension pipe **41966** to the outlet of 47788 using a 2½" clamp.

6. Install another **41966** extension pipe to the top outlet connection of the muffler. Install LH tail pipe **47789** to the outlet of 41966. Install clamp-on rod hanger **36315** at the inlet end of the extension pipe in the rubber isolator. Install another **41966** extension pipe at the outlet of 47789.
7. Install **36316** hanger on the LH lower spring shackle bolt. Install the included nut and washer on the shackle bolt. Rotate the bottom portion of the hanger 90° (use pliers) to seat on the pipe and use a 2½" clamp to secure the bottom of the hanger to the tail pipe. Finger tighten 2½" clamps at the tail pipe connection to the muffler and on the connection of 41966 to 47789.
8. Beginning at the inlet end, align all components and tighten all the clamps. Please see system diagram on back page of these instructions.

KIT CONTAINS:

- (1) 17758 MUFFLER
- (1) 55255 PIPE
- (1) 47788 TAIL PIPE
- (1) 47789 TAIL PIPE
- (3) 41966 EXTENSION PIPE
- (1) 36314 CLAMP-ON HANGER
- (1) 36315 CLAMP-ON HANGER
- (1) 36316 HANGER
- (8) 2½" CLAMPS
- (1) 701608 INSTRUCTION SHEET

19420 SYSTEM DIAGRAM

