

Installation Instructions for Dynamax Bracket 36152 and Rubber Isolator 35460
1999 – 2004 Jeep Grand Cherokee

1. Remove the OE tail pipe rear metal rod hanger bracket that is bolted to the outside of the vehicle R.H. (passenger side) frame. This rod hanger is attached to the frame with two bolts.
2. In its place, bolt in the Dynamax rod hanger bracket 36152. Position this bracket so that the rod end is pointed outboard to the right hand (passenger side) side of the vehicle.
3. Slip the OE rubber isolator, or the Walker / Dynamax rubber isolator 35460, onto the rod hanger of bracket 36152.
4. The Dynamax exhaust system, including the tail pipe, can now be correctly installed on the Jeep Grand Cherokee.