

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX VT MUFFLER KIT: 38488**

2010 Ford Mustang 4.6L V8
2010 Ford Shelby GT500 5.4L
Stainless Steel Dual VT Muffler Axle-Back System



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Please read all instructions before starting any work.

1. The DynoMax VT mufflers will install onto the original equipment (OE) front pipes. Remove the original mufflers by loosening the muffler inlet pipes clamps and muffler rod hanger bracket assemblies from the vehicle underbody. Loosen the inlet clamps on the OE front pipes. You may need to re-position the front pipes when installing the DynoMax mufflers.
2. Remove the rod hanger bracket assemblies from the original mufflers and install these on the DynoMax VT muffler, 53858 (RH) and 53859 (LH). Be sure to note the correct location and installation position of each hanger bracket assembly
3. Install the DynoMax VT mufflers by inserting the muffler inlet pipes onto the OE front pipes and bolting rod hanger bracket assemblies to the vehicle under body. Use the DynoMax band clamps supplied to clamp the VT mufflers to the outlet of the OE front pipes.

4. Install DynoMax stainless steel tips 36505 on each muffler outlet connection.
5. Beginning at the inlet end, position the muffler and tips and tighten all clamps.
6. Start the vehicle and check for exhaust leaks. Retighten and position as required.

KIT CONTAINS:

- (1) 53858 RH VT MUFFLER
- (1) 53859 LH VT MUFFLER
- (2) 36505 SS TIP w/3" BAND CLAMPS
- (2) 36438 2½" BAND CLAMPS
- (1) 713037 INSTRUCTION SHEET

38488 SYSTEM DIAGRAM

