

**INSTALLATION INSTRUCTIONS FOR  
DYNOMAX KIT: 39461**

2008-04 Dodge Ram 2500/3500 5.9L Diesel, 2 / 4 WD



2701 N. Dettman Rd.  
Jackson, MI 49201

**DANGER WARNING:** SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

**NOTE:** Read all instructions before beginning the installation.

1. Remove the OE inlet pipe/muffler/tail pipe welded assembly from the vehicle. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers. Do **NOT** remove the exhaust pipe just ahead of the welded muffler assembly.
2. Slip a band clamp on the inlet end and install DynoMax inlet pipe **51072**. Insert the metal rod hanger into the rubber isolator on the passenger side frame. Do not tighten the band clamp at this time.
3. Slip a band clamp over the inlet end and install DynoMax Ultra Flo Welded muffler **17557**. Do not tighten the band clamp at this time.
4. Slip a band clamp over the inlet end and install DynoMax tail pipe **55563**. Insert the metal rod hangers into the three (3) rubber isolators on the chassis and frame

5. Install DynoMax SS tip **36477** using supplied band clamp.
6. Beginning at the inlet end, align the system and fully tighten all the clamps.
7. Please see the system diagram on the back page of these instructions.

**KIT CONTAINS:**

- (1) 17557 MUFFLER
- (1) 51072 INLET PIPE
- (1) 55563 TAIL PIPE
- (1) 36477 SS TIP
- (4) 4" BAND CLAMPS
- (1) 710780 INSTRUCTION SHEET

# 39461 SYSTEM DIAGRAM

