

INSTALLATION INSTRUCTIONS FOR

DynoMax KIT: 39532

2015 Chevrolet Tahoe / GMC Yukon w/5.3L V8



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL THIS EXHAUST PRODUCT AT HOME, BE WARNED THAT LIGHT DUTY TRUCK "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS. FAILURE TO HEED THIS WARNING COULD RESULT IN SEVERE INJURY OR DEATH.

NOTE: Please read all instructions before beginning the installation.

1. Remove the existing inlet pipe/muffler/tail pipe assembly from the vehicle. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers.
2. Install DynoMax front pipe **52546**. Install replacement clamp **36522** on the inlet end. Slightly tighten the clamp.
3. Install DynoMax Ultra Flo Welded muffler **17233** with the side connection as the inlet end. The muffler should lie flat when installed. Slightly tighten a **33272** inlet clamp.
4. Install DynoMax over-axle pipe **53922**. Insert the two (2) metal rod hangers into the rubber isolators on the chassis. Slightly tighten a **33272** clamp to the muffler outlet.
5. Install DynoMax tail pipe **53923**. Insert the metal rod hanger into the rubber isolator on the chassis. Slightly tighten the **36439** clamp to the over-axle pipe.
6. Install DynoMax SS tip **36474** using the included 3" band clamp.
7. Beginning at the inlet end, align the exhaust system components and fully tighten all the clamps.
8. Please see the system diagram on the back page of these instructions.

KIT CONTAINS:

- (1) 52546 Inlet Pipe
- (1) 17233 UF Welded Muffler
- (1) 53922 Over-Axle Pipe
- (1) 53923 Tail Pipe
- (1) 36474 SS Tip w/3" Clamp
- (1) 36522 Spherical Clamp
- (1) 36439 SS Band Clamp
- (2) 33272 Mega Band Clamp
- (1) 82277579 Instruction Sheet

39532 SYSTEM DIAGRAM

