



INSTALLATION INSTRUCTIONS
PLEASE READ THE FOLLOWING INSTRUCTIONS CAREFULLY AND
THOROUGHLY BEFORE INSTALLING YOU NEW CARBURETOR BOLTS

CATALOG #1925 Carburetor bolts for Edelbrock Performer Series Replacement Carbs for Q-Jet Applications

MODEL: Carburetor bolts for Edelbrock Performer Series Replacement Carburetors for Q-Jet Applications #1901– #1904.

INSTALLATION INSTRUCTIONS: Refer to carburetor installation instructions if necessary. Install bolts with washers in the original location: two long bolts with washers at the front and two short ones in the rear. Be sure to install the throttle linkage bracket (if equipped) to the rear of the carb with the two short bolts & washers. Torque all bolts to 10 ft./lbs.