

Holland 5th wheel bushing installation instructions

© 2004 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Install the bushing without the sleeve into the riser. Put a light coating of grease on the sleeve and then insert into the bushing.

17172
12/23/96 KN
Updated 17/MAR/04 BRH

Holland 5th wheel bushing installation instructions

© 2004 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Install the bushing without the sleeve into the riser. Put a light coating of grease on the sleeve and then insert into the bushing.

17172
12/23/96 KN
Updated 17/MAR/04 BRH

Holland 5th wheel bushing installation instructions

© 2004 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Install the bushing without the sleeve into the riser. Put a light coating of grease on the sleeve and then insert into the bushing.

17172
12/23/96 KN
Updated 17/MAR/04 BRH

Holland 5th wheel bushing installation instructions

© 2004 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Install the bushing without the sleeve into the riser. Put a light coating of grease on the sleeve and then insert into the bushing.

17172
12/23/96 KN
Updated 17/MAR/04 BRH

B.O.M. For Master set # 18-18101

18-18101.cdr
23/JUL/02 BRH
Updated 15/MAR/04 BRH

Parts list:

Front control arm bushing set: 18-3101

- 2 - 3397 Bushing, control arm.
- 2 - 7109 Bushing, strut rod.
- 2 - 7110 Bushing, strut rod.
- 2 - 2463 Bushing, control arm.
- 2 - 3398 Bushing, control arm.
- 1 - 17349 Installation Instructions.

Rear control arm bushing set: 18-3102

- 2 - 3390 Bushing, trailing arm.
- 16 - 3389 Bushing, lateral link.
- 4 - 8256 Bushing, trailing arm.
- 4 - 15.10.437.39 (.875" x .500" x 1.650" sleeve)
- 4 - 15.10.438.39 (.875" x .563" x 1.650" sleeve)
- 1 - 17350 Installation Instructions

Front sway bar bushing set: 18-5101

- 2 - 5620 1-1/8" I.D. Bushings.

Rear sway bar bushing set: 18-5102

- 2 - 5575 15mm I.D. Bushings.

Tie rod boot set: 9.13101

- 2 - 13001

Grease: Formula 5 Prelube.

- 2 - 9.11101 grease tubs..

Misc:

- 1 - 17370 Parts list.

Packaging Instructions



All sleeves and instructions for each set must be packaged together in individual bags.

Fold the parts list # 17370 so the

"OPEN FIRST!!

On the Master set # 18.18101"
Is clearly visible when packaged on skin packing card.