

# OPEN FIRST!!



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

## Parts list for Master set # 4-18105 66-77 4WD Ford Bronco 4° offset

© 2002 Energy Suspension. All rights reserved.  
May not be reproduced, in any form, or by any means,  
without the written consent of Energy Suspension.

**Note:** It is recommended that this set be professionally installed if you are unfamiliar with this type of work, and a factory service manual be purchased prior to performing any work on your vehicle for proper disassembly, reassembly and torque specs. These instructions are intended for bushing removal and install of Energy Suspension polyurethane bushings, once you have removed the factory component from your vehicle.

### Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and parts list **before you start**.

#### Transmission mount set: 4-1101

- 2 - 1001 mounts (top)
- 2 - 1002 mounts (bottom)
- 2 - 15.10.101.39 (.750" x .563" x 1.875" sleeve)
- 4 - 15.03.16.39 (2-1/2" O.D. washer)

#### Front radius/strut arm bushing set: 4-7107

- 4 - 7049 bushings
- 1 - 17230 installation instructions

#### Front 4 degree "C"-bushing set: 4-7102

- 4 - 7015 bushings
- 1 - 17231 installation instructions

#### Front track arm bushing set: 4-7108

-1966-75 vehicles use the following:  
(round eye each end)

- 2 - 2501 bushings
- 1 - 15.10.18.39 (1.00" x .750" x 1.750" sleeve)
- 2 - 2502 bushings
- 1 - 15.10.05.39 (.750" x .563" x 1.750" sleeve)
- 1 - 17039 installation instructions

#### 1976-77 vehicles use the following: 4-7116

(oval eye one end)

- 2 - 2501 bushings
  - 1 - 15.10.18.39 (1.00" x .750" x 1.750" sleeve)
  - 2 - 7038 bushings
  - 1 - 15.10.80.39 (.875" x .625" x 1.800" sleeve)
- use 17039 installation instructions

#### Rear leaf spring and shackle bushing set: 4-2102

- 8 - 2048 leaf spring bushings
- 4 - 15.10.35.39 (.875" x .625" x 2.750" sleeve)
- 4 - 2056 rear frame shackle bushings
- 2 - 15.10.06.39 (.750" x .563" x 2.750" sleeve)
- 1 - 17040 installation instructions

### Parts list continued:

#### Body mount set: 4-4110

- 8 - 4025 bushings (top)
- 8 - 4026 bushings (bottom)
- 8 - 15.10.59.39 (.875" x .750" x 1.5" sleeve)
- 8 - 15.07.02.40 (7/16"-14 nut)
- 8 - 15.03.07.39 (2-1/2" x 7/16" washer)
- 8 - 15.03.09.39 (2" x 7/16" washer)
- 8 - 15.03.04.39 (1-1/8" x 7/16" washer)
- 4 - 15.05.08.39 (7/16"-14 x 3" bolt)
- 4 - 15.05.09.39 (7/16"-14 x 4" bolt)
- 1 - 17030 installation instructions

#### Tie-rod boot sets:

- 4 - 13001 tie-rod boots

#### Grease:

- 2 - 9.11101 grease tubs

## Additional parts available for

### Shock boots

fits most aftermarket shocks (2 per set)  
set # 9-8130

### Swaybar and endlink bushings

Please refer to our newest catalog for more information please ask to see catalog at your place of purchase.

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, etc. please ask to see catalog at your place of purchase.

# 17199

1/08/97 KN  
Updated 23/Aug/02