OPEN FIRST!!

Parts list for Master set # 7-18101 1970-73 Datsun 240Z



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2005 Energy Suspension. All rights reserved. May not be reproduced, in any form, or by any means, without the written consent of Energy Suspension.

Parts list:

Energy Suspension recommends that you read over all the installation instructions and check all P/N's and quantities in the parts list before you start. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Front tension rod bushing set: 7-7102

4 - 7020 bushings

2 - 15.10.65.39 (.688"O.D. x .500"I.D. x 2.000" sleeve)

Front control arm bushing set: 7-3106

2 - 3060 bushings

2 - 15.10.55.39 (.750"O.D. x .562"I.D. x 2.450" sleeve)

2 - 3061 bushings

1 - 17019 installation instructions

2 - 9.11108 grease

Steering coupler set: 7-16101

1 - 16001 bushings

4 - 15.10.162.39 (.500"O.D. x .375"I.D. x .880"sleeve)

4 - 15.10.240.39 (.500"OD. X .313"I.D. X .875"sleeve)

Rack and pinion bushing set: 7-10101

1 - 10014.1(top drivers side)

1 - 10014.2(bottom drivers side)

1 - 10015.1(top passenger side)

1 - 10015.2(bottom passenger side)

1 - 17077 installation instructions

Rear control arm bushing set: 7-3104

8 - 3062 bushings (hub end)

4 - 15.10.70.39 (.750"O.D. x .630"I.D. x 1.830" sleeve)

4 - 3078 bushings (inner rear position)

2 - 15.10.49.39 (1.187"O.D. x 1.005"I.D. x 2.450" sleeve)

4 - 3077 bushings (inner front position)

2 - 15.10.95.39 (1.187"O.D. x 1.005"I.D. x 2.062"sleeve)

1 - 17019 installation instructions

2 - 9.11108 grease

Rear mustache bar bushing set: 7-1102

Must reuse existing outer metal shell

4 - 1006 bushings

2 - 15.10.67.39 (.875"O.D. x .625"I.D. x 2.600" sleeve) 4 - 15.03.24.39 (2-1/2" O.D. x 5/8" I.D. washer)

1 - 17064 installation instructions

1 - 9.11108 grease

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list continued:

Front end link set: 9-8120

8 - 4806 end link grommets

8 - 15.03.01.39 (cupped washers)

2 - 15.10.22.39 (.562"O.D. x .375"I.D. x 1.650" sleeve)

2 - 15.05.02.39 (3/8"-16 x 5-1/2" bolt) 2 - 15.07.01.39 (3/8"-16 nut)

Front and rear bump stop set: 7-6104

4 - 6016 bushings

Tie rod boots: 9-13103 2 - 13003 tie rod boots

Additional parts available for your vehicle:

Swaybar bushings

Front frame bushings Bar dia. Set # 16mm 7-5112 7-5101 18mm 20mm 7-5102

Transmission crossmember mount bushing set: Set # 7-1101

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.