Installation Instructions





PRO-KIT # 28108.540

2011-12, Jeep Grand Cherokee, 2WD/4WD, V6 & V8, Exc. SRT8

Note: Vehicles with self leveling rear shocks will require replacement with a non self leveling shock

Kit Contents	Description	Part Number	Qty	
	Front Spring	28108.001	2	
	Rear Spring	28108.002	2	
	Bump Stop, Front	1J0412303	2	
	Information Kit	EPAK	1	
	Instructions	28108.540INST	1	

NOTES: Read All Instructions Before Beginning Installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist is highly recommended and will substantially reduce installation time.
- Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.
- **PRO-KIT** springs are marked with a .001, for Front and .002, for the Rear.
- **PRO-KIT** springs should be installed with the Eibach Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the **PRO-KIT** Springs.
- After installation, it is always important to inspect and adjust the following if necessary:
 - Wheel alignment such as camber, caster & toe
 - Tire and/or wheel fender clearance, when aftermarket tires and wheels are used.
 - Brake line clearance and attachments
 - Brake anti-locking and anti-skid system sensors
- **Tire Rotation:** In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.
- For MacPherson Strut type front suspension, it is important to mark the orientation of the upper perch with respect to the lower perch before disassembly. This orientation must remain the same with the installation of the Pro Kit springs. Noise may result if this procedure is not performed correctly.

ALIGNMENT:

After installation, it will be necessary to perform a full vehicle alignment. Eibach offers the following alignment kits for this vehicle.

