

# **20081**

**01-02 CHEVY**  
**HEAVY DUTY**  
**FULL FACE**  
**BILLET GRILLE**



# **20082**

**01-02 CHEVY**  
**HEAVY DUTY**  
**FULL FACE**  
**BILLET GRILLE**

**NOTE: This Billet Grille Replaces Entire Grille Shell**

**Tools Required:**

7/16" Socket & Ratchet  
7/16" Wrench

**Hardware / Parts Included:**

1 - Billet Grille (31 bars)  
8 - 1/4-20 x 3/4 Bolts  
16- 1/4 Flat Washers  
8 - 1/4 Lock Washers  
8 - 1/4-20 Nuts

**Read and understand instructions before attempting installation**

**Step 1.**

Remove the black cover over the radiator. Now remove the grille shell from the vehicle. Place the billet grille onto the truck. Push both ends in between the headlight and the lower turn signal; set the complete grille in the truck until the face is flush with the headlights and turn signals. The upper brackets should line up to the header panel.

**Step 2.**

There are two upper brackets and two lower that need to be bolted to the header panel. It may be necessary to slightly bend these brackets by hand to ensure a perfect fit. Align the remaining brackets to the header panel. Fasten using the remaining nuts and bolts.

**Step 3.**

Check that the hardware is tight and replace the radiator cover. The inner two brackets on top of the grille will now mount to the radiator cover. Installation is now complete.

*Thank you for purchasing a T-Rex Billet Grille.*