

25501
08-11 FORD
ECONOLINE
XLT VAN



25501
08-11 FORD
ECONOLINE
XLT VAN

08-11 FORD ECONOLINE XLT VAN

Bumper Billet 1 Pc.

TOOLS REQUIRED:

8mm/10mm Socket or Nut Driver
Flat / Phillips Screwdrivers
Plastic Pry Bar

PARTS LIST:

(3) Custom Ford Van Bumper Brackets
(3) #8 6 Head 1-1/4" Screws
(3) #8 U-Nuts
(1) Billet Grilles



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquires can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1

Open the vehicles hood and remove four plastic pop clips and one 10mm bolt from the top of the factory grille (Fig 1). With the top of the factory grille loose, pull the bottom corners outward, there are 3 latches along the bottom that should pop loose (you can use a screwdriver to help unlatch the latches if needed). Take the three custom u shaped brackets and install the three u-nuts onto them with the barbed side installed away from the bent ends (Fig 2) the arrow points at the barbs. Now take the billet grille and insert it into the bumper opening (Fig 3). Now take the three screws and insert them through the billet bars and the small square tabs with the hole in the center that are welded to the backside of the billet (Fig 4). From the backside of the bumper take the three brackets with the u-nuts and place them with the bent ends facing the front of the vehicle, the screws will insert into the u-nuts, tighten with a phillips screwdriver (Fig 5). Reinstall the factory grille. Installation complete.

