



25511

99-04 FORD

MUSTANG

BUMPER BILLET

Tools Required:

Phillip Screw Driver Drill 1/8" Drill Bit

Parts List:

- 1 Bumper Billet Insert
- 2 #8 x ³/₄ Phillips Screws
- 2 #8 Flat Nuts

Read and understand instructions before attempting installation

Step 1

Center the billet insert in the bumper opening. Drill and fasten the brackets at each end of the bumper billet using the hardware provided. Installation complete. *Thank you for purchasing a T-Rex billet grille*.

2/10/04 T-Rex Truck Products Inc.