

T-REX

Billet Grilles

52205

07-08 GMC

SIERRA

52205

07-08 GMC

SIERRA

UPPER CLASS SERIES BUMPER

Recommended Tools:

Phillips / Slotted Screwdrivers
19mm Socket & Ratchet
Drill & 3/16" Bit
Die Grinder or Jig-Saw (Optional)

Parts List / Hardware:

1	Mesh Bumper	2	6-32 x 2" Machine Screws
8	#10 Flat Washers	2	Fender Washers
8	6-32 Nylon Lock Nuts		




Read and understand instructions before attempting installation

Step 1

Use a screw driver to remove the license plate. The factory license plate mount is held to the bumper airdam by four aluminum rivets. Drill the rivets out with 3/16" drill. Remove and retain to re-install the license plate. Use a 19mm (or 3/4") socket to remove the factory tow hooks.

Step 2

Test fit the grille into the bumper opening. The grille has six studs welded to the back; use these as a guide to mark the holes onto the airdam. Drill 3/16" holes at each mark. Re-center the grille; from behind the airdam, secure each screw using the smaller #10 washers and lock nuts.



Step 3

The factory license plate mount can be modified to mount on the bumper billet. A portion of the license plate mount must be trimmed to re-install. As shown; apply a strip of masking tape to draw a line on each end (1). Use a die grinder to remove the excess material from the license plate mount (2). The last picture shows a profile view of the license mount after your cuts (3). Center the upper mounting holes on the plate mount to the factory holes in the air dam. Install the 2" machine screws and fender washers into the upper mounting holes; secure the screws from behind the air dam using the remaining #10 washers and lock nuts. ***Thank you for purchasing your T-Rex billet grille. 1/24/07***