

55910
52910
2013 TOYOTA
AVALON



55910
52910
2013 TOYOTA
AVALON

2013 TOYOTA AVALON

Bumper Grille Install time: 20 Mins.

TOOLS REQUIRED:

Socketwrench

PARTS LIST:

- (1) Mesh Grille
- (10) 6/32 Nylon Lock Nuts
- (10) 6/32 Flatwashers
- (2) Spacer

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

- Remove Clips and Bolts to remove the Front Facia.
- Remove 4 Screws along the Top of the Factory Bumper. (Fig. 1)
- Unclip 18 Clips from around the Grille and Remove. (Fig. 2)
- Place the Mesh Grille onto the Bumper Opening. (Fig. 3)
- Place 6/32 Flatwashers and Nylon Lock Nuts onto the Threaded Studs on the Mesh Grille. (Fig. 4)
- Place the Spacer onto the Opening Hole on the Mesh Grille. (Fig. 5)

INSTALLATION COMPLETE

