

55812
2011-13 INFINITI
G37



55812
2011-13 INFINITI
G37

2011-13 INFINITI G37

Bumper Mesh Grille

Install time: 25 Mins.

TOOLS REQUIRED:

Socketwrench
Flat Screwdriver

PARTS LIST:

(1) Mesh Grille
(4) Fender Flatwashers
(4) 6/32 Nylon Lock Nuts

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

- Remove Screws and Clips along the Top of the Plastic Cover. (Fig. 1)
- Slide Forward the Plastic Cover and Lift Up a bit. (Fig. 2)
- There will be Clips that are connected to a black hose, Remove these Clips and Remove the Plastic Cover. (Fig. 3)
- Place the Mesh Grille onto the Bumper Opening. (Fig. 4)
- From behind the Grille, Place a Fender Flatwasher and Nylon Lock Nut. (Fig. 5)
Repeat for remaining Threaded Studs

INSTALLATION COMPLETE

