

6714900
6714901
97-06 JEEP
WRANGLER



6714900
6714901
97-06 JEEP
WRANGLER

97-06 JEEP WRANGLER

X-Metal - Studded Main Grille 1 Pc.

Install time: 45 Mins.

TOOLS REQUIRED:

Screwdriver
Jigsaw/Grinder

PARTS LIST:

(7) Mesh Grille	(4) #8 6head 1" Screws
(8) U-Nuts	(2) L-Brackets
(4) Fender Flatwashers	(2) 3 x 2½ Brackets
(4) #10 1" Screws	

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

- Insert U-Nuts through the holes on all the Brackets. (Fig. 1)
 - Mark along the Grille Shell Ribs close enough to the Factory Grill Shell, With a jigsaw cut all the Grille Shell Ribs. (Fig. 2)
 - Place the 3 x 2½ Bracket on the first Large Hole along the underside of the Grille Shell (The longer side of the bracket goes downward) Place a Fender Flatwasher on the #10 Screw and Thread the 3 x 2½ Bracket in place. (Fig. 3 & Fig. 3A & Fig. 4)
 - Place the L-Bracket along the bottom of the Grille Shell on the second hole with the longer side of the L-Bracket going upwards then place a Fender Flatwasher through the #10 1" Screw from underneath the car to thread the L-Bracket. (Screw will be placed on the 2nd large Hole.) (Fig. 5)
 - Place Mesh Grille through the Grill Shell. (Fig. 6)
 - Insert #8 6head Screw through the Bracket on the Mesh Grille to thread the U-Nut on the L-Bracket. (Fig. 7)
- Repeat for remaining Screws.

Installation Complete

