



**Remote Mount Power Steering Reservoir Bracket
1970-74 E-Body Mopar
BHS590**



Installation Instructions

Thank you for choosing to use HOOKER™ engine swap mounting brackets as part of your GEN3 HEMI Swap project. These mounting brackets are part of the most comprehensively engineered system of mounting components, headers and exhaust systems available for this application. Please read these instructions thoroughly before attempting installation.

PRE-INSTALLATION CONSIDERATIONS:

BHS590 Power Steering reservoir bracket is designed to allow a remote power steering reservoir to be used when Gen 3 Hemi on pump reservoirs contact the battery tray. See compatibility information below for a list of supporting parts required.

The parts list below is intended for use with Holley Power steering Pump kits listed below, any other pump configuration will require additional parts and or modifications to the pump that are not outlined here.

Visit www.holley.com for a complete selection of Transmission Crossmember, Headers, Exhaust, and more GEN3 HEMI support products to complete your E-Body Hemi Swap.

COMPATIBILITY INFORMATION:

- 198-212 Holley Remote power steering reservoir
- 97-382 Holley GEN 3 Hemi Swap Power steering Pump kit - 2014 up car and truck accessory drive
- 97-379 Holley GEN 3 Hemi Swap Power steering Pump kit - up to 2013 NON-VVT car and truck accessory drive
- PS0003ERL Earls remote power steering reservoir adapter kit
- Reservoir to pump and return lines will need to be fabricated to work with your combination of parts – see www.holley.com for a complete line of Earl's hose and fittings to complete this installation.

PARTS LIST:

| Qty. | Description |
|------|----------------------------|
| 1 | Reservoir Mounting Bracket |

ACCESSORY PACK CONTENTS:

| | | |
|---|-----------|----------------------------|
| 2 | | 1/4 - 20 x 1/2 Bolts |
| 2 | | 1/4 - 20 X 1" Bolts |
| 4 | | 1/4 - 20 Flange Nuts |
| 2 | 599R94 | Decal – Blackheart 2" x 4" |
| 1 | 199R12230 | Instruction Sheet |

Check the hardware package. If anything is missing, please contact Technical Service at 1-866-464-6553 or 270-781-9741.

TOOLS NEEDED:

| |
|---------------------|
| Standard Socket Set |
| 7/16 Wrench |

INSTALLATION OF BLACKHEART BHS590:

1. Using the existing mounting points that correspond to the bracket. Install the BHS590 bracket to the driver's side inner fender using the supplied $\frac{1}{4}$ x 1" bolts as shown in Figure 1. **NOTE:** Use supplied nuts if holes are not pre-threaded or if new holes are being added.
2. Install the 198-212 reservoir (sold separately) to the bracket with the supplied $\frac{1}{4}$ x $\frac{1}{2}$ " bolts.

NOTE: If mounting holes are not present in the OEM or aftermarket inner fender, use the bracket as a template to drill the holes in the correct location.



Figure 1



Figure 2

Any questions? Please contact Technical Service: 1-866-464-6553 or 270-781-9741. For online help, please refer to: www.holley.com.

© 2021 Hooker Headers, Inc. All rights reserved. Tous Droits Réservés.

199R12230

Date: 5-26-21