

Installation Instructions for 50061, 50062, 50084, & 50086

Bug Catcher Style Scoop

Dual Quad Applications

Parts Included:

Hood Air Scoop	1 pc	Air Cleaner Stud Wing Nut	2 pcs
Air Cleaner Top	2 pcs	Air Filter Element	2 pcs
Throttle Arm	1 pc		
Air Cleaner Stud	2 pcs		

1. Remove the existing air cleaner unit from carburetor.
2. By rotating the throttle rod, check to make sure that throttle plates turn without hitting the scoop or support brackets. Make any necessary clearance adjustments to the plates so that there is no contact with the scoop. Then tighten securely the throttle plate screws.
3. Screw air cleaner studs into carburetors. Check length of studs with air scoop clearance. If needed, cut studs to desired length.
4. Set the base mounting flanges onto the carburetors. Place air filter elements and air cleaner tops onto the base mounting flanges. Next, use the air cleaner stud wing nuts to tighten entire assembly to the carburetors.
5. Place the air scoop over top of the air cleaner unit so that tapered holes line up with the slots in the base mounting flanges. Use the 1/4"-20 x 1/2" whiz lock screws & 1/4" flat washers to fasten base mounting flanges to the air scoop securely. Need to insert the screws from the underside of the base flanges and screw into the tapered holes on the air scoop.
6. The carburetor linkage attached to the scoop must work freely and without binding. User discretion is advised.
7. Before closing the hood, check air scoop for proper clearance.

Note: This product is not legal for street use on pollution-controlled vehicles.



1-800-345-4545 jeps.com