

Installation Instructions for 53550 LS Coolant Crossover

NOTE: For use on some applications the rear crossover ports will need to be drilled using a Letter C drill bit.

Tip: Install both front and rear crossover lines on the adapters before installing the adaptors onto the cylinder heads. Do not tighten until adaptors are secured in place.

