

Installation Instructions for 555-60198

Note:

Chevrolet and GM TH700R4 transmissions may require modification to the starter pocket (increased cut out size) in order for flexplate dust cover to fit. Refer to area in illustration “A” for potential interference. Trim to fit if interference with starter is evident.

Note: Measure and compare the existing dust cover first due to 700R4 versions with different bolt spacing.

“illustration A” - Possible Interference Area Highlighted In Red

