

# Installation Instructions for 64072

## Front Motor Plate

### for Chevy LS Series

**NOTE:** You will reuse the O.E. water pump bolts during this installation.

