

Installation Instructions for 81157

Mechanic Seat with Drawers

300 lb. Capacity

Assembly Instructions:

1. Put the base frame on the flat floor.
2. Insert the gas cylinder into the hole of base frame.
3. Insert the sleeve out of the gas cylinder.
4. Put the round tray on the sleeve.
5. Place seat cushion on top of the assembled base frame.
6. Rated Capacity: 300 lbs.

Part	Description	Quantity
1	Seat Cushion	1
2	Round Tray	1
3	Sleeve	1
4	Gas Cylinder	1
5	EVA Liner 1	2
6	EVA Liner 2	1
7	EVA Liner for Drawer	2
8	Drawer	2
9	Base Frame	1
10	2.5" Caster Wheels	4

