

## ***Installation Instructions for W83011***

### ***Cable Tie Tool***

#### ***CV Joint Boot Clamp Band Tool***

1. Slide the CV band through the nose of the banding tool and into the winding mechanism.
2. Place the band over the CV joint and into the seat of the boot.
3. Use the winding handle on the side to start taking up slack in the band.
4. Continue until it's tightened to the manufacturer's specifications on the boot. It may be necessary to use a socket or wrench on the winding handle to achieve proper torque.
5. Now simply bend the tool forward towards the folding tabs. The bend will hold the band in place while you release enough from the winding for a clean cut.
6. Cut the band and use a small hammer or punch to peen the tabs over locking the band in place.



**1-800-345-4545 [jeps.com](http://jeps.com)**