

## LOCATION CHART GUIDE

### CHEVROLET

<u>YEAR</u>	<u>MODEL</u>	<u>CHART#</u>
1986-1995	Astro Van	1
1981	Camaro	4
1982-1993	Camaro	2
1981-1982	Corvette	5
1984-1990	Corvette	2
1984-1995	C/K 10,20,30	3
1982-1988	Monte Carlo	1
1984-1994	S10/GMC S15	2
1991-1995	Corvette	6
1988-1994	Beretta	1
1986-1994	Cavalier	3

### PONTIAC

<u>YEAR</u>	<u>MODEL</u>	<u>CHART#</u>
1981	Firebird	4
1982-1993	Firebird	2
1988-1991	Gran Prix	1

### OLDSMOBILE & BUICK

<u>YEAR</u>	<u>MODEL</u>	<u>CHART#</u>
1983-1987	Regal	1
1983-1989	Cutlass	1

#### E.C.M. LOCATION CHART

1. Behind Passenger Kick Panel
2. Under Dash (passenger side)
3. Behind Glove Compartment
4. In Center Console
5. Behind Drivers Seat (next to battery)
6. Drivers Side Under Hood

# INSTALLATION

JET Powertech Performance chips (Stage 1 or 2) are easily installed in less than thirty minutes.

Disconnect negative side of battery. Locate the ECM (see ECM Location Chart). Remove the mounting screws with nut driver or socket (usually 1/4", 7mm or 10 mm), and pull the ECM out. Remove the access cover with appropriate screwdriver. Carefully remove the stock chip from its socket, then gently insert the Powertech chip. Replace the access cover and the ECM and thats it.

