

JET Power-Flo
Throttle Body Spacer Installation Instructions
Nissan 3.3L Frontier/Pathfinder/Xterra
Part #62147

1. **Remove Air Intake Assembly from throttle body.**
2. **Remove the 4 bolts that mount the throttle body to the intake manifold**
3. **Remove the gasket and clean any residue from the surfaces. Be careful not to get any gasket material in the intake manifold.**
4. **Remove the bolts that mount the throttle linkage bracket and retain for latter use.**
5. **Install the JET Power-Flo throttle body spacer using one gasket between the intake manifold and the spacer and one gasket between the throttle body and the spacer.**
6. **Replace the 4 bolts that mount the throttle body to the intake manifold using the new bolts and flat washers supplied in the kit.**
7. **Install the new linkage extender plates using the allen head screws. Reinstall and reconnect the linkage assembly and reconnect the cables to the throttle body.**
8. **Verify the throttle linkage ,cruise control and kick down cables are NOT binding and that the travel on the linkage is correct before you start the vehicle. NOTE: In some instances it may be necessary to readjust the cables for proper travel, refer to your factory service manual for correct adjustment procedures.**
9. **Reinstall the Air Intake assembly.**