



INSTALLATION INSTRUCTIONS

P/N 37934, 37936, 37938

Drill and tap 8-32 hole on center of the dowel hole .400" below the block bell housing face.

Dowels may need to be fitted to case, die to factory dowel hole tolerance is .628-.620.
To do this; polish the lower portion of the dowel until it slips into the dowel bore.

PARTS LIST P/N 37934

2- 8-32 x 3/8" Set Screws
2- .007 Offset Dowels

PARTS LIST P/N 37936

2- 8-32 x 3/8" Set Screws
2- .014 Offset Dowels

PARTS LIST P/N 37938

2- 8-32 x 3/8" Set Screws
2- .014 Offset Dowels

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 8:30am – 5:00pm Eastern Time**

*MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437-2116
Phone: (203) 453-6571 • Fax: (203) 453-6906*