



## INSTALLATION INSTRUCTIONS

### P/N 39020 and 39021 HOOD PIN SETS

**NOTE:** We highly recommend at least six hood pins per hood, when the hood pins are the only means of attachment.

#### INSTALLATION

For each pin (refer to diagram for component location).

1. Determine hood pin location and mount pin.
2. Drill 17/32 hole in hood.
3. Place scuff plate over pin and drill 4 mounting holes, use 3 fasteners to attach.
4. Thread lanyard through fourth hole and crimp rivet eyelet.
5. Adjust pin height to desired location.

#### PARTS LIST #39020

- |   |                        |
|---|------------------------|
| 4 | 1/2-20 JAM NUT         |
| 2 | HOOD PIN 1/2-20 CHROME |
| 2 | SCUFF PLATE            |
| 2 | HOOD PIN CLIP (CHROME) |
| 2 | LANYARDS               |
| 2 | RIVER EYELET           |

#### PARTS LIST #39021

- |   |                         |
|---|-------------------------|
| 4 | 7/16-20 RH JAM NUT      |
| 2 | HOOD PIN 7/17-20 CHROME |
| 2 | SCUFF PLATE             |
| 2 | HOOD PIN CLIP (CHROME)  |
| 2 | LANYARDS                |
| 2 | RIVER EYELET            |



**For Technical Assistance, Call Moroso's Tech Line at  
(203) 458-0542, 458-0546 8:30am - 5:00pm Eastern Time**

MOROSO PERFORMANCE PRODUCTS, INC  
80 CARTER DR • GUILFORD, CT 06437  
Phone: (203) 453-6571 • Fax: (203) 453-6906