



## **INSTALLATION INSTRUCTIONS**

### **P/N 71900**

These washers are designed to index any spark plug to any cylinder. There are (10) washers of each thickness (.010", .021", .032"). They are to be used with 14mm Tapered-Seat Plugs Only.

### **INSTALLATION**

1. Mark the plug insulator inline with where the electrode is.
2. Screw the plug into the cylinder and torque to 10 ft/lbs.
3. Note the electrode location and how many degrees it has to be rotated to be in the proper position.
4. Select the proper washer and install it on the plug. The .010" washers will rotate the plug counterclockwise 105°; the .021" washers will rotate the plug 210°; and the .032" washers will rotate the plug 315°.
5. Tighten to 10 ft/lbs.
6. Check to make sure the electrode is in the proper location.

**Note: The Washers may be reused many times, as long as they are not over tightened.**

**For Technical Assistance, Call Moroso's Tech Line at  
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time**

MOROSO PERFORMANCE PRODUCTS, INC  
80 CARTER DR • GUILFORD, CT 06437-2116  
Phone: (203) 453-6571 • Fax: (203) 453-6906