



OIL FILTER ADAPTER KIT CHEVROLET V-8 1968-86 – #1272

INSTALLATION INSTRUCTIONS

1. Check and be sure oil filter cavity in engine block is clean and free from dirt or oil sludge.
2. Check mounting bolt threads, use a thread chaser tap to clean and correct thread pitch if necessary.
3. Install oil filter adapter into oil filter cavity so by-pass valve in adapter is facing inward (toward crankshaft), no gasket sealer is required.
4. Install two 5/16"- 18 x 1.00" mounting bolts supplied and tighten to factory torque specification. Refer to vehicle manufacturer's service manual for fastener torque specification.
5. Use Fram PH30 (short) or PH13 (long) oil filter or equivalent. Install oil filter onto threaded nipple, be sure to lubricate rubber seal and tighten securely. Check for oil leaks once engine is started.

Note: Thread size on nipple is 13/16"-16, this is the factory thread size for Chevrolet V-8 engines 1968-86.

CONTENTS OF KIT:

	Qty.
Oil filter adapter	1
Mounting bolts (5/16"-18 x 1.00"L)	2

THE ACCEL PERFORMANCE GROUP

*Mr. Gasket is a trademark of ACCEL Performance Group
Mr. Gasket es un a marca comercial de ACCEL Performance Group
Cleveland, Ohio ©2016 www.mr-gasket.com*

FORM 97141272
04/12
Printed in China