



HUMMER H2 FRONT APRON COVER INSTALLATION INSTRUCTIONS

2003-2008 HUMMER H2 #404206

Congratulations on your purchase of a high quality PUTCO product.
Should you need any application or technical assistance feel free to call us at: 1-800-247-3974
Monday-Friday 8:00 a.m. - 5:00 p.m. (Central Standard Time)
Contact your PUTCO dealer for other quality accessories.
PUTCO Inc. - 216 West First Street - Story City, Iowa 50248

Please read all instructions first before beginning installation.

Step 1: Remove the protective wrapping from part.

Step 2: Loosen the (8) bolts that attach the bumper to the front apron. You can access these bolts through the wheel well openings and between the skid plate and apron.

NOTE: You will need an extension to access the bolts in the center of the bumper.

Step 3: Install the front apron cover on to the vehicle.

Step 4: Check the alignment and fitment before tightening the bolts.

Step 5: Tighten all bolts you loosened in **(Step 2)** to secure the front apron cover in place.

Step 6: Recheck all bolts to ensure that the part is secured to the vehicle.

Note: PUTCO recommends applying a high quality automotive wax to maintain the original appearance on your new Hummer H2 Front Apron Cover.

INSTRUCTION # IN404206-MAR 2008

LIMITED WARRANTY

Putco guarantees it's Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. Black products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco.