

# INSTALLATION INSTRUCTIONS

## PREMIUM LED DOME LIGHT KIT

#980013 (2008 Ford Super Duty Crew Cab)

# PUTCO



Please note: You must follow these instructions to install the parts correctly otherwise damage may occur.  
Read all instructions before installation and check to see if all parts listed are included.

### DOME LIGHTS

Front

Middle

Rear



### PREMIUM LED DOME LIGHT INSTALLATION



Questions? Call Putco's customer service at 1-800-247-3974  
Monday - Friday, 8am - 5pm central time  
216 West First Street ▪ Story City, IA ▪ 50248  
[www.putco.com](http://www.putco.com)

#### LIMITED WARRANTY

Putco guarantees its products against defects in workmanship and material for as long as you own your vehicle. All painted products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco. Putco is not liable for any vehicle damage resulting from the installation of our Pure LED Premium Dome Lights.