



Installation

Clean glass thoroughly.

Install the gasket on the glass making sure the corners are aligned properly.

For gaskets without corners, make sure you place the vulcanized seam in the bottom middle of the glass.

Insert a 1/4" diameter rope in the center of the bottom* section of the gasket. Starting at the bottom* and overlapping 6 to 8 inches.

Spray the gasket with soapy water solution to help ease the installation.

Lay the glass and gasket into the vehicle opening making sure it is aligned squarely.

Start pulling the rope from inside the vehicle working slowly across the bottom* and up the sides and finally across the top*. Gently pat the glass into place with a flat hand from the outside.

Once the glass is in place lock the channel by inserting in the locking strip in the groove on the bottom center of the gasket.

Some locking strips are round while others have a specific shape that must match the groove properly.

Most locking strips can be worked into place with a windshield stick and patience, but there are special tools available that allow for easier installation. Contact your PRP distributor for the right tool for your application.

Note: Windshield installations after 1978 should be sealed with a urethane adhesive.

Follow the urethane adhesives manufacturer's installation procedures.