



## **Installation**

Clean glass thoroughly

Apply gasket onto glass. Starting at the corners making sure corners and trim slots are in the right locations.

Insert trim completely into groove. You may need to tape trim onto molding and glass.

Insert a 1/4" diameter rope in the center of the bottom\* section of the gasket. Starting at the bottom\* and overlapping 6 to 8 inches.

Spray the gasket with soapy water solution to help ease the installation.

Lay the glass and gasket into the vehicle opening making sure it is aligned squarely.

Start pulling the rope from inside the vehicle working slowly across the bottom\* and up the sides and finally across the top\*. Gently pat the glass into place with a flat hand from the outside.

\* For Chevy trucks 67-72 you will want to start at the top center and finish at the bottom with the rope.

**Note:** Windshield installations after 1978 should be sealed with a urethane adhesive.  
Follow the urethane adhesive manufacturer's installation procedures.