

**20-inch Dual Row LED Light Bar
Hidden Bumper Mounting Brackets
Dodge 2010-15 Ram 2500/3500 4WD/2WD**

Parts:

1 - Driver Side Bracket
1 - Passenger Side Bracket
8 - 12mm x 45mm Bolts
8 - 1/2" Flat Washers

PRE-INSTALLATION

Professional installation by a certified technician is strongly recommended.

Not responsible for altered products. No claims are made regarding any after-market devices. Any and all claims implied in this document excluded.

NOTES:

Light bar not included in kit.

REQUIRED TOOLS:

18mm Socket 19mm Socket

INSTALLATION INSTRUCTIONS

- STEP 1:** Disconnect positive battery lead before installation.
- STEP 2:** Remove four factory bolts securing each tow hook. (18mm Socket)
- STEP 3:** Place bracket behind tow hook with light bar tab to the inside.
- STEP 4:** Replace tow hook.
- STEP 5:** Secure with included 12mm x 45mm bolt and washer - Hand tighten.
- STEP 6:** Repeat process on other side.
- STEP 7:** Install 20" light bar with hardware included with kit.
- STEP 8:** Tighten all tow hook bolts. (19mm Socket)
- STEP 9:** Wire power to light bar per instructions supplied with kit.
- STEP 10:** Reconnect positive battery lead.

POST-INSTALLATION

MAINTENANCE: Periodically check to ensure that all fasteners are properly tightened.