



**Installation Instructions for PROFORM®
Billet Aluminum Timing Tab with LED Timing Light**
Adjustable • Permanently Mounted Light • Hands-Free

1. Remove your old timing tab, and install your new tab with light.
2. When ready to use, unplug black moisture-seal plug from light module, and plug in the pick-up wire in its place.
3. Attach the other end of the inductive pick-up unit wire by opening the slide on the attaching end, and then placing it over the #1 spark plug wire.
4. Important: make sure all other spark plug wires are positioned as far away from the pick-up unit as possible -- otherwise you may pick up signals from another cylinder.
5. Start engine, and set timing.
6. When finished, shut engine off, unplug pick-up from light module, and replace it with the moisture-seal black plug.
7. Disconnect the pick-up from the #1 wire, and store in toolbox or other safe area.