



R I N G B R O T H E R S

E4829 Hwy 14 • Spring Green, WI 53588 • 608.588.7399 • www.ringbrothers.com • info@ringbrothers.com

81684-1041 & 81684-1042 1968-74 Ventura Billet Hood Hinge Kit Installation Instructions

Thank you for purchasing your set of billet hinges from Ringbrothers - the innovators of the billet hinges. What you have purchased is an original and not a copy.

If you plan to disassemble the hinges before installation for polishing or plating you should know that all the bolts are assembled with blue Loctite. This should be done again when hinges are reassembled.

Also, note when disassembling the hinges, that there are two small washers to provide clearance for the pivot bearings on the forward support arms. Make sure that they are replaced when the hinges are reassembled.

Packing List:

- 1 – Right hinge assembly
- 1 – Left hinge assembly
- 4 – 3/8" x 1" button head bolts with washers for attaching hinge body to inner fender
- 4 – 3/8" x 1-1/4" button head bolts with washers for attaching hinge bracket to hood
- 2 – Gas springs

CAUTION: Make sure ALL bolts are not too long for your application.

Tools Needed:

- 9/16" Socket, open end or box end for removing factory hinges
- 7/32" Allen wrench for installing 3/8" button head bolts
- 11/32" and 3/8" Open end wrenches for hood adjustment height link



Installation Steps

1. Remove hood
2. Remove factory hinges and try to hand tighten a button head bolt where each hinge bolt was removed. If the threads are damaged or corroded re-tap them with a 3/8"-16 tap.
3. Position each hinge on the correct side and attach the hinge body to the inner fender with the 3/8" x 1" button head bolts. Before tightening the bolts completely, move the hinge body up or down so the bolt is centered in the slot.
4. Each hinge has a gas spring to hold the hood open.
NOTE: When installing the gas strut the barrel of the spring should always be above the rod to keep the lubrication on the rod and not ruin the spring. The spring should be installed after the hinge is mounted to the fender but before the hood is installed
5. Before you attach the hood you need to make sure that the hinges will close square. Measure the hood to hinge mounting holes. Measuring across the hood, record the length between the front two mounting holes. Then record the measurement between the rear two mounting holes on the hood. With the hinges mounted to the car you will need to measure and record the length between the front two holes on the hood bracket. Do the same for the rear two holes on the hood bracket – just as you did on the hood. You are making sure that the measurements are close because the hinges will NOT FLEX.
NOTE: it may be necessary to loosen the inner fender bolts to adjust the hinge mounting surface in or out.
NOTE: HINGES MUST CLOSE SQUARE! THEY WILL NOT FLEX!
6. Attach the hood to the hinges with the 3/8" x 1-1/4" button head bolts. Slide the hood forward as far as possible tightening the bolts. This will assure that the hood will not hit the cowl as it is lowered. Lower the hood **carefully**, watching the clearance front and back as well as both sides. Adjust the hood on the hinge brackets as needed for the correct clearance.
7. Adjust the hood height. Once the hood closes completely, check the height of the hood at the rear corners. If the hood is too high lower the entire hinge on the inner fender. If the hood is too low raise it by adjusting the short link with rod end bearings. **Be aware that adjusting the height this way will also move the hood slightly forward so the hood may have to be repositioned on the hinge brackets.** Tighten the jam nuts when the adjustment is complete.

Any questions please call 608-588-7399
Enjoy your new Ringbrothers Billet Hinges!
