

INSTRUCTIONS:

This three wire door iamb switch has completed contacts on all three wires

when the switch is at rest (door open). To use in typical applications, you will use two of the three wires, one wire to ground and the other to your interior light(s) activation circuit. In Ron Francis Wiring kits, the interior light activation circuit is a grey wire. The third wire on the door jamb switch is not needed but can be used for additional interior light (grey wire) circuits.