

INSTRUCTIONS:

One of these resistors is required per side of vehicle (left and right). Mount the LR-26 securely to a metal base as this unit will get hot and a good mounting surface will help dissipate the heat. One lead must go to a good ground. Tie the remaining lead into a wire/circuit to the front turn signal for that side of the vehicle.

For the left side LR-26, one lead will tie into the left front turn signal circuit. For the right side LR-26, one lead will tie into the right front turn signal circuit.