



**1970-1979 Ford F-150 / Bronco
OEM Replacement Steering
Stabilizer
Part # 7030**

Contents:

Part #	Description	Qty
7800	WHITE STEERING DAMPER	1
142120	STAB WASH PKG	2
STEM BUSH-SST	STEM BUSHING-STEERING STAB.	4
B10RS	RED BOOT	1
BTIE	RED BOOT TIE	1
HSS	HYDRO SHOCK DECAL	1
I-7030	INST. SHEET FOR 7030	1

Installation Instruction:

1. Clean and dry all surfaces before starting.
2. Turn wheels to a straight forward position.
3. Remove factory steering stabilizer from the vehicle.
4. Install one washer and then poly bushing on each end of new stabilizer and install on vehicle.
5. Now install one poly bushing then washer on each end.
6. Tighten until bushings start to squeeze out around washer.
7. Re-tighten all bolts after the first 100 miles and periodically thereafter.

Thank you for choosing SKYJACKER.

Seat Belts Save Lives, Please Wear Your Seat Belt.



Available Accessories:

Stainless Steel Braided Brake Lines
Dual Shock Kits
Radius Arm Bushings
Track Bar Bushings

Contact Your Dealer for Part Numbers and Pricing!

I-7030 1-03