



87-96 Jeep Wrangler YJ Single Steering Stabilizer Part # 7109

Bill Of Material

Part#	Description	Qty
7900WS	WHITE STEERING DAMPER	1
BTIE	RED BOOT TIE	1
B10RS	RED BOOT	1
HSS	HYDRO SHOCK DECAL	1
83031	MAIN BRKT - 7109	1
83161	UNIVERSAL TIE ROD BRACKET	1
38X312FTB	3/8 X 3 1/2 FINE THREAD BOLT	2
516X1X134U	5/16 X 1 X 1 3/4 U-BOLT RD	2
38FTN	3/8-24 FINE N/I LOCK NUT	2
38SAEW	3/8 SAE WASHER	2
516CTN	5/16-18 COARSE N/I LOCK NUT	4
516SAEW	5/16 SAE WASHER	4
STEM BUSH-SST	STEM BUSHING-STEERING STAB.	4
142120	STAB WASH PKG - P889/145098	2

(Park the vehicle on level ground with the tires pointing straight forward).

1. PASSENGER SIDE: Place straight frame bracket against inside of frame directly above drag link. (There may be a rubber frame shield, which is clipped at this spot. If so, pull shield at corner and it should pop loose.) Mark and drill the 2 holes in the frame.
2. Move any hoses or lines that may get in the way of drilling as not to damage them in the drilling process. Drill through frame with 3/8" drill bit. Bolt bracket into place with hardware furnished. Re-connect frame shield.
3. Install the boot & tie onto the stabilizer. Mount the angled bracket on to the drag link (this is the link going to the pitman arm), loosely, using u-bolts, nuts and washers furnished. Attach main end of stabilizer to main bracket using hardware furnished. Pull stabilizer rod out 4". Attach stabilizer to drag link bracket using hardware furnished. Tighten bracket at this time.
4. Re-tighten all bolts at this time. Re-tighten after the first 100 miles and periodically thereafter.
5. Thank you for choosing Skyjacker!

Seat Belts Save Lives, Please Wear Your Seat Belt.