

Universal 60" Wide UTV Roof

Thank you for choosing Rough Country for all your UTV needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product. Check all fasteners for proper torque. Check to ensure for adequate clearance between all components. Periodically check all hardware for tightness.

KIT CONTENTS:

- (2) Roof Sections
- (1) 5' Molding
- (12) 1/4"-20 x 3/4" Bolts
- (12) 1/4"-20 Acorn Nuts
- (24) 1/4" Flat Washers
- (6) 1/4" x 1" Fender Washers
- (6) 1/4"-28 x 1" Bolts
- (6) 1/4"-28 Nylock Nuts
- (6) Black Spacers
- (6) 1/4" P-clamps

TOOLS NEEDED:

- 1/4" Drill
- Drill Motor
- 7/16" Socket/Wrench
- Ratchet
- Marker
- Knife or Scissors

▲ NOTICE

The mounting of this roof is not intended to hold for transporting on an open trailer or truck. It must be removed or secured with a secondary device for such transporting. We are not responsible for loss or damage due to transporting on and open trailer or vehicle.

Installation Instructions

1. Working from one side to the other, slide the supplied H molding onto one of the roof sections. **Leave some of the molding overhanging on each side, to be trimmed flush with the edge after the roof assembly is complete. See Photos 1 & 2.**



Photo 1



Photo 2

2. Working from one side to the other, slide the second roof half into the H molding. **Make sure to get the roof halves tight together. See Photos 3 & 4.**



3. Place the assembled roof onto the ROPS cage as seen in **Photo 5.**



4. Start with the outside assembly part. Transfer the $\frac{1}{4}$ " hole through the roof with the hand drill one at a time putting in the supplied $\frac{1}{4}$ "-20 x $\frac{3}{4}$ " bolts with a $\frac{1}{4}$ " washer on the top and bottom securing them with the acorn nuts. **See Photos 6 & 7.**



5. Transfer the center assembly part holes through the roof and secure in place with the 1/4"-20 x 3/4" bolts with a 1/4" washer on the top and bottom securing them with the acorn nuts. **See Photo 8**
6. Using



- a knife or scissors, cut the H molding off flush with the roof edge. **See Photo 9.**
7. Place the assembled roof on top of your UTV.
 8. Place the (4) supplied P-clamps on the ROPS, in the furthest most locations possible, in the corners of the roof where you can put a supplied bolt through with the 1" fender washers. Mark these locations on the roof.
 9. Place the remaining (2) P-clamps on the ROPS, as close to the H molding where the roof halves come together and to the edge of the UTV. Mark these locations on the roof.
 10. Using a 1/4" drill, drill the marked locations from steps 8 & 9.
 11. Install the supplied 1/4" x 1" bolts through the supplied 1" fender washers then through the roof and the P-clamp. Install the supplied 1/4"-28 nylock nuts on the bolts. Tighten using a 7/16" socket and wrench.

▲ NOTICE

On the Kawasaki models you will need to put the black plastic spacer in between the P-Clamp and the roof to allow space for the welded brackets of the ROPS

Thank you for choosing Rough Country for all your UTV needs.

By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims or indirectly from the purchase, ownership, or use of the items.



