



JEEP JK FRONT DANA 30 DIFF/SKID

Thank you for choosing Rough Country for your suspension needs.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware against the parts list. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools.

PRODUCT USE INFORMATION

Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

If question exist we will be happy to answer any questions concerning the design, function, and correct use of our products by calling 1-800-222-7023.

This JK diff/skid is designed to work with any JK with stock with a dana 30 front axle.

Kit Picture



Tools Needed

- 1/2" Socket
- 9/16" Socket

Install Instructions

1. Remove the 5 lower bolts holding the inspection cover to the axle with a 1/2" socket.
2. Hold the diff/skid against the outside of the inspection cover and insert the supplied bolts. **See Photo 1.**
3. Insert the supplied u-bolt around the pinion flange and secure with a supplied flange nuts. **See Photo 2.**
4. Tighten the diff bolts with a 1/2" socket and the u-bolt nuts with a 9/16" socket.



Photo 1



Photo 2