## TOTANS Part #2458 PERFORMANCE PRODUCTS Instructions

This package contains a large and small diameter fitting to match the fuel line fittings on your TBI unit. Attempting to install the wrong fitting will damage TBI fuel fitting threads.



- 1. Ensure the fuel system is depressurized.
- Detach the fuel lines from the TBI unit fuel fittings. Check that any old seals/orings are removed from the TBI unit fittings. DO NOT REMOVE the fuel line fitting from the TBI unit!
- Apply a small amount of lubricant to the o-rings and install on extensions as shown here.
- 4. Thread male end of extension fittings into TBI fuel line fittings and tighten.
- Attach the fuel lines to the female end of the extension fittings and tighten.
- Pressurize fuel system and check for leaks.

tel: 562.921.0404 email: techsupport@hedman.com