



Platinum Series Bug Shield

No Drill BUG DEFLECTOR

Installation Instruction: T

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bugshield by holding it up to the hood.
(This will also help verify if you have the correct shield for your vehicle).
- 3) Remove the weather-stripping and all the plastic pushpins (to remove the plastic pushpins you can use a pair of pliers or a fork).

Remember: The Bugshield eliminates the need for the weather-stripping.

- 4) Insert nylon push pin
Before locking push pin in place by pushing in the nylon plugs make certain the shield is properly centered by "eyeballing" the two ends (you may need to move the shield to either the left or right).
- 5) Push in push pin
- 6) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

3- 14007 push pins

www.wadeauto.com
www.westinautomotive.com