Installation Instructions for 50301 **Big Block Ford Timing Cover** for 429/460

Installation Instructions:

Carburetion WITH dipstick in front cover and HAS a fuel pump

1. Install original dipstick tube in dipstick hole (hardware kit is not needed).

Carburetion with NO dipstick in front cover and HAS a fuel pump

1. Install dipstick plug in dipstick tube hole. Insert plug by hand first, lightly tap plug in place with mallet making sure plug is fully seated when finished.

Fuel injection with NO dipstick in front cover and NO fuel pump

- 1. Install dipstick plug in dipstick tube hole. insert plug by hand first, lightly tap plug with mallet making sure plug is fully seated when finished.
- 2. Install fuel pump block-off plate and gasket over fuel pump mounting.

Fuel injection ('91 and later) with NO dipstick in front cover and NO fuel pump

- 1. Install dipstick plug in dipstick tube hole. insert plug by hand first, lightly tap plug with mallet making sure plug is fully seated when finished.
- 2. Install special 5/16th studs with Loctite in front cover oil pan bolt holes.
- 3. Install fuel pump block-off plate and gasket over fuel pump mounting.



1-800-345-4545 jegs.com