## Installation Instructions for 75050 & 75051 Self Fusing Tape

## **Installation Instructions:**

- 1. Clean surface that the tape will be applied to.
- 2. Make two wraps where the tape begins. Use the blue line on the tape as a guide and spiral the tape with a slight pull to ensure a tight bond.
- 3. When the area is covered, make two wraps at the end to seal the tape.

